

# PREDELIVERY CHECKLIST

Sprayer Model: \_\_\_\_\_

Frame Serial Number: \_\_\_\_\_

It is the dealer's responsibility to ensure that this machine is correctly assembled and pre-delivered prior to retail. This form must be completed and returned with the MACHINE COMMISSIONING & WARRANTY REGISTRATION CERTIFICATE (Form 1040) to **Howard Australia Pty Ltd at:** Private Mailbag 5, SEVEN HILLS NSW 1730 or by fax to 02 9674 6263.

to indicate completed.

Dealer: ..... Town & Post Code: .....

## PRE DELIVERY / FINAL ASSEMBLY ADJUSTMENTS

- Check paint work for defects.
- Check decals are correct and are free of defects.
- Check all tanks are clean and are free of defects.



Check Fame / Chassis & Suspension fastener tensions.

- M8 22Nm (16 ftlbs).
- M10 44Nm (32 ftlbs).
- M12 77Nm (57 ftlbs).
- M16 190Nm (80 ftlbs).
- M18 269Nm (198 ftlbs).
- M20 337 Nm (250 ftlbs).

Wheels

- Wheel nut tension studs. 22mm 490 Nm (361 ftlbs).
- Adjusted tyre pressures to suit field conditions.

- Check operation of pump.
- Check operation of FILL, FUNCTION and SOURCE valves plus Pressure Controller.
- Check all hoses are free of leaks and kinking.
- Check operation of all valves.
- Check operation of tank rinse nozzles.
- Check operation of all nozzles. Nozzles fitted: \_\_\_\_\_
- Check for leaks.
- Check filters for correct filter size.
- Check and clean all in line filters.



- Fit Boom / Plumb Boom sections accordingly.
- Check operation of Hydraulics / Boom (opens and closes correctly).
- Check hydraulics for leaks.
- Adjust Boom - Refer Operation Manual.
- Fan blades (Airblast) are tightened and set; Refer Operation Manual.

Final machine run test.

- Check operation of controllers / monitors.
- Check wiring is correct for sprayer.
- Wiring is secure and not rubbing.
- Flow-meter / speed sensor fitted.

Optional Equipment. Check fitment is correct and functioning. Record options fitted.

*Note: Further adjustment will be required after a short period of work.*



### LUBRICATION

Add lubricant and/or check lubricant level in Diaphragm pump, Hydraulic pump and Gearboxes (Airblast).



Grease all bearings and pivot points, including PTO shaft sliding members, Boom pivot points, breakaway points and Self levelling system.

Notes:

Pre-delivered by: ..... Signed: ..... Date: .....